


## Sensors & Master-Slave Installations.



**Photo Cell (Photo Beams or edge sensors)** are required on each individual installation to prevent gate from hitting persons or vehicles.

**Reversing Sensors:** Reversing Sensors on the ground floor prevent gate from closing when a vehicle is in the loop area.

**Exit Loops:** Exit Loops on the ground floor opens gate when a vehicle crosses the loop area.




Figure 9